

Information Data Sheet

Painting Tilt-up Concrete Slabs

- The surface should be clean, dry and free from all dirt, dust, grease, oil and any other surface contamination.
- Prior to painting please check with the manufacturer if any bondbreaker has been used.
- Remove all traces of bondbreakers by applying a bondbreaker dissolving agent from bottom to top and allow to penetrate and hose off with copious amounts of water.
- All residues must be removed.
- Any areas where the bondbreaker is thick or overlapped may require a second application.
- High-pressure water blast alone will not remove heavy build up particularly on interior surfaces not exposed to weather.
- **All tilt form concrete should be allowed to cure for a minimum of 28 days and the alkalinity must be PH10 or below before painting can commence.**
- Grind smooth any nibs and protrusions and fill blowholes and defects with an appropriate filler or patch. Then follow paint manufacturers specification.

See: Australian Standard AS 3730.22-2006

